

<b>VAS 14X88-425</b>	<b>Varishock OEM Bolt-In</b>		
<b>Make</b>	<b>MODEL</b>	<b>YEAR</b>	<b>F/R</b>
Chevrolet Truck	Blazer 2 WD Compact , C models	69-83	F
Chevrolet Truck	Pickup (1/2 ton) 2 WD (Silverado, C & R Models)	63-87	F
Chevrolet Truck	Pickup (3/4 ton) 2 WD (Silverado, C & R Models)	63-89	F
Chevrolet Truck	Suburban (1/2 ton) 2 WD (C & R Models)	63-91	F
Chevrolet Truck	Suburban (3/4 ton) 2 WD (C & R Models)	63-91	F
Chevrolet Truck	Van- Step van (1/2 ton) P models Forward Control	63-84	F
Chevrolet Truck	Van- Step van (3/4 ton) P models Forward Control	68-89	F
GMC Truck	Jimmy 2 WD Compact , C models	69-83	F
GMC Truck	Pickup (1/2 ton) 2 WD (Sierra, C & R Models)	63-87	F
GMC Truck	Pickup (3/4 ton) 2 WD (Sierra, C & R Models)	63-89	F
GMC Truck	Suburban (1/2 ton) 2 WD (Sierra, C & R Models)	63-91	F
GMC Truck	Suburban (3/4 ton) 2 WD (Sierra, C & R Models)	63-91	F
GMC Truck	Van- Step van (1/2 ton) P models Forward Control	63-84	F
GMC Truck	Van- Step van (3/4 ton) P models Forward Control	68-89	F
Saab	Series 99	68-80	F
Willys	Aero	54-55	F

**Part Number**

**Explanation:**

Replace the "X" in the part number with a 1 when purchasing QuickSet 1 or a 2 for QuickSet 2 style shocks