

6106

TIE ROD ADAPTERS FOR MUSTANG II and NEW PINTO RACK

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	1505	Tie rod adapter

These tie rod adapters are designed for use with '74-'78 Mustang II, '74-'80 Pinto rack and pinions, and '71-'72 New Pinto racks with 9/16 diameter tie rods.

1. Adapters can be used to lengthen up to 1 1/4 inches or shorten the tie rods up to 4".
2. Assemble the front suspension and determine the change in tie rod length. Saw the tie rod in half centered between the end of the rack boot and the beginning of the tie rod threads. Shorten the ends the appropriate amount and slide them into the rack adapter equal distances. Weld the tie rod adapter to the tie rod. Also, weld up the 4 1/4 inch holes making sure the tie rod welds to the adapter through the 1/4 inch hole.
3. Some tie rods are a little smaller than the bore in the adapter. They will work as long as you weld them in straight.
4. To attach the Mustang II style rack and pinion to Mustang II spindles, use Chassisworks Tie Rod Kit #6118. To attach the '71-'72 New Pinto rack to Mustang II spindles, use Chassisworks Tie Rod Kit #6107.

Revision Date: May 14, 2003

