

6115
ADJUSTABLE UPPER SPRING MOUNT, 1 5/8 FRAME

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	2309	Shock mount bracket - right
2	2	2310	Shock mount bracket - left
3	2	2127	Upper adjustable mount 1 5/8 frame
4	2	3200	Locknut 1/2 - 20
5	4	3209	Locknut 3/8 - 24
6	4	3115	Bolt 3/8 - 24 x 1 1/4
7	2	3100	Bolt 1/2 - 20 x 2 1/4

This mount provides approximately 3 inches of ride height adjustment and is designed for use with VariShock or Koni coil-overs.

1. Position the adjustable mount on the frame per the assembly drawing provided with the frame.
2. Look at your assembly drawing to find the correct location for the shock mount brackets. Bolt one right and one left bracket to each side of the frame bracket. Secure with the 3/8 bolts and locknuts. VariShock coil-overs have misalignment bushings built into the shock eyes. Other brands of shocks may require optional misalignment bushings (our part no. 1000). If necessary put one 1/2" misalignment bushing (part no. 1000) on each side of the coil-over eye and secure in place with the 1/2" inch bolt and locknut.

Revision Date: May 7, 2004

