

6279
FLAT-SUFACE SHOCK-MOUNT KIT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	4	1000	Misalignment bushings .50" bore x .25" length
2	4	2125	Flat-surface mount tab, 1/2" hole
3	2	3100-050F2.50Y	Bolt 1/2-20 x 2-1/2" hex head, Grade 8
4	2	3101-050-20C	Locknut 1/2-20 nylon insert

1. Refer to the blueprint supplied with your chassis for the correct location of this shock mount.
2. The brackets may be trimmed to better fit the mounting surface or to match the shock angle. They should be spaced apart to allow enough clearance for the shock bearing and misalignment bushings.

Revision Date: November 28, 2008



6279
FLAT-SUFACE SHOCK-MOUNT KIT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	4	1000	Misalignment bushings .50" bore x .25" length
2	4	2125	Flat-surface mount tab, 1/2" hole
3	2	3100-050F2.50Y	Bolt 1/2-20 x 2-1/2" hex head, Grade 8
4	2	3101-050-20C	Locknut 1/2-20 nylon insert

1. Refer to the blueprint supplied with your chassis for the correct location of this shock mount.
2. The brackets may be trimmed to better fit the mounting surface or to match the shock angle. They should be spaced apart to allow enough clearance for the shock bearing and misalignment bushings.

Revision Date: November 28, 2008

