

# VAS 512-1-2



## COM-8 1" Extended Top Shock Eye (pair)

Part Number	Description	Qty
899-010-213	COM-8 Top Loop 1" Longer with 1" Bore & 9/16-18 Thread	2

### INSTRUCTIONS

1. Remove the bearing's retaining ring with snap ring pliers and remove the bearing from the eye.
2. Hold the currently installed top shock eye in a vise, then loosen the jam nut.
3. Once the jam nut is loose the billet mount can be unscrewed from the piston shaft by hand.
4. Thread the new extended eye onto the shock shaft.
5. Securely hold the top shock eye in a vise, then tighten the jam nut against the base of the eye. Use a rag between the vise and eye to prevent scarring the eye. The vise only needs to be tight enough to stop the eye from spinning as the jam nut is tightened.
6. Insert the bearing in the new shock eye and secure with the retaining ring. Use a small punch to make sure the retaining ring is fully seated in the groove.

Revision Date: March 8, 2012

899-031-256

# VAS 512-1-2



## COM-8 1" Extended Top Shock Eye (pair)

Part Number	Description	Qty
899-010-213	COM-8 Top Loop 1" Longer with 1" Bore & 9/16-18 Thread	2

### INSTRUCTIONS

1. Remove the bearing's retaining ring with snap ring pliers and remove the bearing from the eye.
2. Hold the currently installed top shock eye in a vise, then loosen the jam nut.
3. Once the jam nut is loose the billet mount can be unscrewed from the piston shaft by hand.
4. Thread the new extended eye onto the shock shaft.
5. Securely hold the top shock eye in a vise, then tighten the jam nut against the base of the eye. Use a rag between the vise and eye to prevent scarring the eye. The vise only needs to be tight enough to stop the eye from spinning as the jam nut is tightened.
6. Insert the bearing in the new shock eye and secure with the retaining ring. Use a small punch to make sure the retaining ring is fully seated in the groove.

Revision Date: March 8, 2012

899-031-256