

6217
INSTRUCTIONS FOR LOWER COIL OVER BRACKETS

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	4	2101	Suspension tab 1/2 hole
2	4	1000	Misalignment bushings 1/2
3	2	3123	Bolt 1/2 - 20 x 2 1/4
4	2	3200	Locknut 1/2 - 20

1. Refer to the blueprint supplied with your chassis for the correct location of this shock mount.

2. The brackets will have to be trimmed to fit the back of your housing. They should be spaced 1 1/16 to 1 1/8 inches apart to allow enough clearance for the shock bearing and misalignment bushings.

Revision Date: April 8, 2005



6217
INSTRUCTIONS FOR LOWER COIL OVER BRACKETS

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	4	2101	Suspension tab 1/2 hole
2	4	1000	Misalignment bushings 1/2
3	2	3123	Bolt 1/2 - 20 x 2 1/4
4	2	3200	Locknut 1/2 - 20

1. Refer to the blueprint supplied with your chassis for the correct location of this shock mount.

2. The brackets will have to be trimmed to fit the back of your housing. They should be spaced 1 1/16 to 1 1/8 inches apart to allow enough clearance for the shock bearing and misalignment bushings.

Revision Date: April 8, 2005

