

6240
PRO STREET LADDER BAR FRONT BOLT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	3126	Bolt 3/4-16 x 3"
2	2	3201	Locknut 3/4-16

This bolt set is for use with #6237 Pro Street ladder bars and all CHASSISWORKS front mounts.

1. Use the 3/4" bolt to attach the front of the pro street ladder bar. The steel sleeve should be greased on the outside where it contacts the urethane. Use the special grease provided with the ladder bars. Also, grease the sides of the urethane where it touches on the ladder bar front mount. The front brackets should be the exact width of the ladder bar bushing sleeve, 1.680. The ladder bar will be a slight press fit between the brackets. Install the 3/4" bolt and locknut then, torque to 65 ft. lbs. The brackets should squeeze the sleeve tightly.

Revision Date: May 23, 2006



6240
PRO STREET LADDER BAR FRONT BOLT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	3126	Bolt 3/4-16 x 3"
2	2	3201	Locknut 3/4-16

This bolt set is for use with #6237 Pro Street ladder bars and all CHASSISWORKS front mounts.

1. Use the 3/4" bolt to attach the front of the pro street ladder bar. The steel sleeve should be greased on the outside where it contacts the urethane. Use the special grease provided with the ladder bars. Also, grease the sides of the urethane where it touches on the ladder bar front mount. The front brackets should be the exact width of the ladder bar bushing sleeve, 1.680. The ladder bar will be a slight press fit between the brackets. Install the 3/4" bolt and locknut then, torque to 65 ft. lbs. The brackets should squeeze the sleeve tightly.

Revision Date: May 23, 2006

