

## 6273 INSTRUCTIONS FOR COIL OVER UPPER CROSSMEMBER

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	E26.134-036.000	Tube 1-5/8 x .134 ERW 36"
2	4	2101	Bracket 1/2 hole

This crossmember can be used with any lower shock mount kit. Depending on the style of the lower mount, it can be installed in front of or behind the rear end.

1. Three brackets weld on the crossmember 1-1/16" to 1-5/16" apart. The misalignment bushings go on each side of the shock bearing when using Koni coil-over shocks. The brackets need to be 1-5/16" apart when using Chassisworks #6225, Coil Spring Assembly. VariShock spherical-bearing coil-overs use 1-1/8" spacing and VariShock poly-eye coil-overs use 1-5/16" spacing.

2. For 5" travel shocks, install the mounts so there is 13" to 13-1/4" at ride height between the upper and lower mounts.

3. After tacking the upper and lower mounts in place, move the suspension through its full travel to make sure the springs and/or shocks do not bind on any part of the rear end or chassis.

Revision Date: February 23, 2009

