

6288

**LADDER BAR ADAPTER BUSHINGS AND BOLTS
FOR PRO STREET ADJUSTABLE LADDER BARS**

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	4	1222	Pivot spacer .750 x .500 bore
2	2	3117	Bolt 1/2 - 20 x 3 1/2
3	2	3200	Locknut 1/2 - 20

This adapter set is used to attach #6287 ladder bars to 3/4" hole front mounts.

1. The pivot spacers install into the front mount one on each side of the rod end. Do not force them in. If there is a burr on the front mount or spacer, carefully file it off. The step of the spacer and the sides of the rod end should be greased. Place the step on the spacers into the 3/4" holes of the front mount. One on each side of the front rod end of the ladder bars. Slide the bolt through the spacers and rod end. Then torque the bolt to 50-ft. lbs.

2. The ladder bar must pivot freely even when the front bolt is torqued. If it does not, eliminate whatever is causing the bind.

Revision Date: March 25, 2004



6288

**LADDER BAR ADAPTER BUSHINGS AND BOLTS
FOR PRO STREET ADJUSTABLE LADDER BARS**

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	4	1222	Pivot spacer .750 x .500 bore
2	2	3117	Bolt 1/2 - 20 x 3 1/2
3	2	3200	Locknut 1/2 - 20

This adapter set is used to attach #6287 ladder bars to 3/4" hole front mounts.

1. The pivot spacers install into the front mount one on each side of the rod end. Do not force them in. If there is a burr on the front mount or spacer, carefully file it off. The step of the spacer and the sides of the rod end should be greased. Place the step on the spacers into the 3/4" holes of the front mount. One on each side of the front rod end of the ladder bars. Slide the bolt through the spacers and rod end. Then torque the bolt to 50-ft. lbs.

2. The ladder bar must pivot freely even when the front bolt is torqued. If it does not, eliminate whatever is causing the bind.

Revision Date: March 25, 2004

