

6403

PARACHUTE STRAP MOUNT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	2303	Folded bracket
2	1	1305	Parachute strap spool
3	1	3200	Locknut 1/2 - 20
4	1	3100	Bolt 1/2 x 2 1/4

1. Attach the folded bracket to the chassis by welding it to a tube that extends out of the body or, by bolting it to a part that is firmly attached to the chassis. The parachute exerts a tremendous pull, don't underestimate the strength required of the chassis mount. Make sure the bracket is centered and at approximately the bumper height.

2. Bolt the spool into the bracket and torque down the bolt. The spool should not rotate. The parachute strap rotates on the spool. The spool does not rotate on the bolt.

Revision Date: May 23, 2006



6403

PARACHUTE STRAP MOUNT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	2303	Folded bracket
2	1	1305	Parachute strap spool
3	1	3200	Locknut 1/2 - 20
4	1	3100	Bolt 1/2 x 2 1/4

1. Attach the folded bracket to the chassis by welding it to a tube that extends out of the body or, by bolting it to a part that is firmly attached to the chassis. The parachute exerts a tremendous pull, don't underestimate the strength required of the chassis mount. Make sure the bracket is centered and at approximately the bumper height.

2. Bolt the spool into the bracket and torque down the bolt. The spool should not rotate. The parachute strap rotates on the spool. The spool does not rotate on the bolt.

Revision Date: May 23, 2006

