

6816

**FRONT SUBFRAME BUSHINGS 67-81 CAMARO**

<u>Item</u>	<u>Qty</u>	<u>Part No.</u>	<u>Description</u>
1	2	1311	Body bushing, 2.0 x .625
2	4	1312	Body bushing, 2.5 x 1.00

These bushings replace the rubber body mounts. The lower rubber bushing is completely discarded. The upper bushing is replaced by the kit bushings. The small bushings go under the radiator support. The large bushings go between the body and front frame, at the firewall and rear of the frame. They will fit 67-81 Camaros and Firebirds, and 68-79 Novas.

1. Loosen all three retaining bolts on one side of the car and pry the rubber bushings out. Install the aluminum bushing between the frame and body. Reinstall the bolt. Repeat this procedure on the other side.

CAUTION: Do not remove all the bolts at one time or you will have to realign the frame and body.

Revision Date: February 18, 2004



6816

**FRONT SUBFRAME BUSHINGS 67-81 CAMARO**

<u>Item</u>	<u>Qty</u>	<u>Part No.</u>	<u>Description</u>
1	2	1311	Body bushing, 2.0 x .625
2	4	1312	Body bushing, 2.5 x 1.00

These bushings replace the rubber body mounts. The lower rubber bushing is completely discarded. The upper bushing is replaced by the kit bushings. The small bushings go under the radiator support. The large bushings go between the body and front frame, at the firewall and rear of the frame. They will fit 67-81 Camaros and Firebirds, and 68-79 Novas.

1. Loosen all three retaining bolts on one side of the car and pry the rubber bushings out. Install the aluminum bushing between the frame and body. Reinstall the bolt. Repeat this procedure on the other side.

CAUTION: Do not remove all the bolts at one time or you will have to realign the frame and body.

Revision Date: February 18, 2004

