

8051
MOPAR 8 3/4" BACK BRACE

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	1046	Mopar 8 3/4" back brace blank

This back brace is designed for Mopar 8 3/4" rear ends.

1. To use on your housing, the back brace will require some grinding. The back brace should be centered on the back of the housing.
2. Shorten the back brace to the correct length before installing.
3. Grind the housing where you will weld on it to remove rust and scale.
4. Whenever possible, weld the ends on the housing after the suspension brackets and back brace. This will prevent their welding operation from bending the housing.

Revision Date: September 2, 2008



8051
MOPAR 8 3/4" BACK BRACE

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	1046	Mopar 8 3/4" back brace blank

This back brace is designed for Mopar 8 3/4" rear ends.

1. To use on your housing, the back brace will require some grinding. The back brace should be centered on the back of the housing.
2. Shorten the back brace to the correct length before installing.
3. Grind the housing where you will weld on it to remove rust and scale.
4. Whenever possible, weld the ends on the housing after the suspension brackets and back brace. This will prevent their welding operation from bending the housing.

Revision Date: September 2, 2008

