

## 7266

**INSTRUCTIONS FOR ELIMINATOR II STRUT FRONT, 4-LINK REAR,  
MILD STEEL, 82 - 94 CORVETTE CHASSIS**

<b><u>ITEM</u></b>	<b><u>QTY</u></b>	<b><u>SIZE/PART NO.</u></b>	<b><u>TUBE CODE</u></b>	<b><u>DESCRIPTION</u></b>
1	2	4140		Cage Side
2	2	4249		Forward strut Eliminator II
3	1	4040		Main Hoop
4	1	4217		Cage top
5	2	4248		Rear frame Eliminator II
6	2	4709		Engine support loop
7	1	1 5/8 x 23	J	Rack and pinion crossmember
8	2	1 5/8 x 108		Front frame 1 5/8
9	2	1 5/8 x 54	A B	Long side bar
10	2	1 5/8 x 24	H	Upper side bar
11	2	1 5/8 x 32	I	Lower side bar
12	2	1 5/8 x 52	C D	Rocker support
13	1	1 5/8 x 54	E	Mid mount
14	1	1 5/8 X 54	F	Main hoop crossmember
15	1	1 5/8 x 54	G	Upper 4-link crossmember
16	2	1 5/8 x 20	J	Rear frame crossmember
17	2	1 5/8 x 29	K	Main hoop rear strut
18	1	1 5/8 x 22	L	Transmission crossmember
19	2	1 5/8 x 12	A B	Foot brace
20	2	1 5/8 x 18	L	Cage side extension
21	2	1 1/4 x 30	U	Rear frame support
22	3	1 1/4 x 24	V	Main hoop to rear strut back brace
23	2	1 1/4 x 36	M	Rear frame Xmember forward support
24	2	1 1/4 x 54	N O	Rocker triangulator
25	2	1 1/4 x 58	P Q	Double rail top
26	2	1 1/4 x 9	N	Rear strut support
27	4	1 1/4 x 6	PQRU	Roll cage gusset
28	1	1 1/4 x 52	R	Cage top triangulator
29	2	1 1/4 x 36	S	Forward strut frame support
30	2	1 1/4 x 34	T	Frame triangulator
31	2	1 1/4 x 25	W	Shock crossmember rear supports
32	2	1 1/4 x 9	O	Double rail frame support
33	4	2015		Frame end cap 1 5/8 round
34	4	3200		Locknut 1/2 - 20
35	4	3100		Bolt 1/2 - 20 x 2 1/4
36	8	1000		Misalignment bushing 1/2
37	16	2101		1/2 hole suspension tabs
38	2	2300		Rack and pinion brackets
39	1	927266		Assembly drawing

**OPTIONAL PIECES FROM FUNNY CAR CAGE #7226**

40	1	4230	Funny car cage auxiliary hoop
41	2	4231	Funny car cage support loops
42	1	1 5/8 X 17	Funny car cage top (made from spare tube from chassis)

All straight tubes are cut from two boxes labeled #4404, they contain the following tubes:

<u>QTY</u>	<u>SIZE</u>	<u>TUBE CODE</u>	<u>ITEM FROM INSTRUCTION</u>
12	1 5/8 x .134 x 72	A	9 and 19
		B	9 and 19
		C	12
		D	12
		E	13
		F	14
		G	15
		H	10 and 10
		I	11 and 11
		J	16, 16 and 17
		K	17 and 17
		L	18, 20 and 20
12	1 1/4 x .134 x 72	M	23 and 23
		N	24, 26 and 26
		O	24, 32 and 32
		P	25 and 27
		Q	25 and 27
		R	28 and 27
		S	29 and 29
		T	30 and 30
		U	21, 21 and 27
		V	22, 22 and 22
		W	31 and 31
		X	Spare

When you receive your chassis, the first thing to do is to make sure you have all the parts. Use the above list of components to verify that you have all the parts. The bent cage parts will usually be banded together in two bundles. The straight tubes will come in two identical boxes labeled #4404. The brackets will be in a small box labeled #3000. The assembly drawing will be in the same 8 1/2 x 11" envelope these instructions were in. If anything is missing, contact Chassisworks for assistance.

The straight tubes boxes will provide enough material to build your chassis provided you cut the correct lengths from each tube. The above chart will give you a guideline. The length of each tube from the instruction sheets are approximate. Do not cut the tubes before you need them and try to cut the long tubes first.

Chassisworks makes no guarantee or claims that this chassis will be accepted by any sanctioning body. It is the sole responsibility of the chassis' owner to determine that this chassis can be used for the owners intended use. We suggest that you carefully examine the rules that pertain to chassis construction for the associations that you race under and, make sure that this chassis fits those rules. We also require you to measure the diameter and wall thickness of every tube (bent and straight) that goes into the chassis to make sure it is the correct size for the rules. With the advent of sonic testing, it is important that you measure the wall thickness of every tube in the roll cage that is subject to the sonic test. See your Association Rule Book to determine which tubes must be a specific minimum wall thickness. Do not install any tube that is not at least the minimum. Chassisworks will replace any tube that is undersized and has not been installed.

Read all the instructions completely and make sure you understand them before you begin. Only tack weld the chassis components whenever possible. This will make it easier to remove components if you make a mistake. All joints that are covered by another tube or bracket must be completely welded before they are covered up. This chassis must be tig (heliarc) welded by an experienced welder - your life depends on it!

Construction of a chassis cannot be accomplished without a jig. To assemble the chassis you will need a level surface as large as the car. This should be a steel table or an "I" beam. You will need to hold the body up off your surface at ride height, the table surface will simulate the ground. Also, weld a little of each joint at a time to help avoid distortion.

Do not assemble your chassis using only the dimensions on the assembly drawing. You must use a body to help in tube placement. The dimensions on the assembly drawing are for a 1982-1994 Corvette.

This chassis can easily be modified to fit other intermediate size cars. Most intermediate size cars are very close to the same width inside. They also have very similar windshield angles. This allows this cage to fit many cars. When altering the dimensions on the assembly drawing for different vehicles, do not change any dimensions that affect where any front or rear suspension brackets mount in relation to other brackets or the chassis will not work.

To vary the wheelbase, lengthen or shorten the distance from the firewall to the front axle centerline. If your body has a shorter wheelbase, do not shorten the driver's compartment more than is absolutely necessary, you need the leg room for the driver.

When altering the dimensions on the assembly drawing for different vehicles, do not change any dimensions that are not inside rectangular boxes. Only the dimensions in the boxes should be altered to fit different vehicles.

Prepare the body for the frame by first measuring forward from the rear axle centerline and marking the rocker panel at 23 inches. This dimension will be used to position the body correctly on the chassis when viewed from the side. The mark on the body at 23 inches should be in line (when viewed from the side) with the back of the main hoop crossmember where the 4-link mounts. This will position the new chassis rear axle centerline in the same location in reference to the body that the stock rear axle centerline had. Measure the stock wheelbase and this will be Dimension A. If you move the front tires forward, add this amount to the wheelbase. If your body was also set back to provide wheel tub clearance, this amount will usually be added to the front fenders to make the front end long enough.

Measure the width of the car at the rocker panels, you will need this dimension later to assure the body is installed at the correct width.

Cut up the body by trimming all inner panels. You just want the single outer skin. You need to attach the body at the rocker panel, A-pillar, B-pillar, rear valance, and top 4 corners of the cage. On steel bodies, weld tabs to the chassis and body that bolt together. This will make it easier to remove and re-install the body as you build the car. Fiberglass bodies should be attached to sheet metal plates and fiber-glassed inside the body. Cleco the body to the plates until the final assembly when the plates should be fiberglassed in. Do not use pop rivets, they will rattle out and crack the fiberglass.

Locate the body off of the jig at the correct ride height. Block the rocker panels and rear of the body so that the car will be held steady. On low cars, like the Corvette, the rear of the body will have to be raised to gain the headroom for the cage. The frame will actually hang down below the body. Your jig will need a centerline from the rear of the car to a point forward of the front axle centerline. A string pulled tight will work fine. This will ensure that all chassis and body parts are centered.

1. Install the main hoop crossmember in the chassis between the rocker panels. To position the main hoop crossmember in the car, you must place the back side 23 inches forward of the rear axle centerline. The rocker supports need to be cut to length and installed with the main hoop crossmember. The rocker tubes should be installed so they are open at both ends. This provides a convenient place to run the battery cables and fuel lines without putting them under the chassis.

2. Install the main hoop per the drawing. It should be as tall as possible to provide adequate headroom. It should be at least 40 inches above the top of the frame. In some low body styles, the rear of the body will have to be raised off the ground to get enough height for the main hoop.

3. Install the upper 4-link crossmember. Use the 4-link chassis mounts to help position it at the correct location.

4. Install the rear frame rails per the dimensions on the assembly drawing. Measure from the back of the main hoop crossmember to the taillight panel. Subtract 23 inches and this will be Dimension D. The frame rails should be centered in the car and 3 inches narrower than the outside width of the 4-link brackets. This will be Dimension F. Make the 4-link brackets outside width as wide as possible while leaving enough room for the rear tires. Install the two rear frame crossmembers per the assembly drawing. Install the rear upper shock mount so it is centered under the frame. Install the chassis 4-link front mounts on the main hoop crossmember and the upper 4-link crossmember. The upper crossmembers front side is even with the main hoop crossmembers rear side when viewed from the side. Two 1/2 x 2 1/4 inch bolts and two 1/2 inch locknuts are used in the upper shock mounts to mount the shocks. The four misalignment bushings are also used in the shock mounts. One goes on each side of the shock bearings to fill the gap in the shock mount bracket. Use #6247 Adjustable Shock Mount for the lower mount.

5. Install the front frame rails per the assembly drawing. Also install the cage top and cage sides per the assembly drawing. Install the front of the cage top as high against the roof as possible. Mount the main hoop end of the cage top on the side of the main hoop to provide more head room for the side of the driver's head. Tack the cage sides in place. Keep the lower leg of the cage side and frame as close to 90 degrees as possible because this will make installation of the firewall easier.

6. Install the cage side extension and foot brace per the assembly drawing, the driver's side and passenger's sides are the same. The rocker supports should be installed under the cage side extension and main hoop. The rocker supports should be positioned so the front and rear ends are open. This will give you an effective and protective tube to run your battery cable and fuel lines through to the front of the chassis. Install the mid mount bar at the correct height.

7. Before you can install the upper strut mounts, you must determine what strut mount width you need for your tires to clear your fenders, this will be Dimension "G". Due to the many different front wheel and tire combinations, you should do the following calculations for your vehicle, even if it is listed in the chart.

**Step 1:** Determine the outside front tire width that you need. Measure the width between the front fenders. You will need 4 to 5 inches of clearance from the side of the tire to the inner front fender lip. Subtract 8 to 10 inches from the inner fender width. This will equal the outside tire width.

**Step 2:** To determine the hub width, you need to know how much wider the outside of the tire is than the front hub. Put a yardstick across the outside of the tire and measure through the center to the side of the wheel that bolts to the hub. When the wheel is bolted on, it is this much wider than the hub. Multiply this by 2 and subtract this amount from the outside tire width you calculated in step one. This will be the required hub width.

**Step 3:** Subtract 11 1/2 inches from the hub width to find the top strut mount width. Write your top mount width on the Assembly Drawing.

Measure forward from the crossmember welded between the rocker panels to locate the front spindle line, this Dimension is equal to "B" and "C". Put a line on both sides of the new front frame rails which will represent the front spindle centerline. All of your brackets will locate off of this line.

8. Install the forward struts with their upper strut mounts. Also install the forward and rear control arm mounts. Check the assembly drawing for their locations and angles. The angle of the brackets is determined by the angle of the control arm leading into them. For best results, position the brackets with the strut and control arms hanging in place. Also, install the rack and pinion mounts and crossmember per the assembly drawing. After all the mounts are tacked in place, install the complete front suspension and steering less the springs. Use the remaining 1/2-inch bolts and misalignment bushings to attach the top of the strut. Align the front end to 1/32 to 1/8 inch toe in, zero degrees camber, and 6 to 10 degrees of caster. The front end can be aligned by using a machinist level on the spindle flats.

Move the strut spindle through its full travel to make sure nothing binds up. Also, check for bump steer. If assembled correctly, all unnecessary bump steer can be removed by shimming the tie rods up and down at the spindle arm or by raising or lowering the rack and pinion slightly (1/16 of an inch at a time).

9. The next step is to install the funny car cage, if you purchased this option.

10. Install the engine support tubes at the mid mount per the drawing (each "U" bend makes 2 parts). If the engine is too far back, it can be moved forward for more windshield clearance. The mid plate attaches to the front of the engine support tubes. Install the tubes at 2 degrees from perpendicular to the frame. Remember, the engine runs uphill to the rear 2 degrees. Install the front engine support tubes with the motor plate to assure the correct location.

Install the transmission crossmember, rocker supports, and frame triangulator when you are installing the transmission crossmember.

11. Position the seat and install the top double rail to clear the seat. If you add more triangulation to the top rail, make sure it will clear the seat.

12. Install the remaining straight tubes, forward frame strut, rear main hoop struts and back brace, rear crossmember and frame supports, side bars and roll cage gussets. Make sure these additional tubes clear all parts of the body.

13. Use the frame end caps to cap the ends of the front and rear frame.

14. Recheck all dimensions, remove the body and finish welding the chassis.

15. Chris Alston's Chassisworks, Inc. carries a complete line of accessories to make completion of your car easier.

Revision Date: May 23, 2006

