

6802

INSTRUCTIONS FOR WINDOW INSTALLATION SPACER KIT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	3505	Rubber spacer 1/2 x 3/4 x 15
2	50	3405	Countersunk bolt 10 - 32 x 1"
3	50	3212	Locknut 10 - 32

The rubber spacer is designed to sit between the stock windshield ledge and the Lexan windshield. The rubber will space the window out 1/2 inch, which is enough to make the windshield flush with the body in most cars.

1. Cut the spacer to the correct length for the four sides of the window opening. Use a weather strip adhesive to glue the rubber to the frame.
2. Place the Lexan window in place and drill 3/16 inch holes through the window, the rubber and the stock window flange. Space the bolts 4 to 5 inches apart.
3. Use an 82 degree countersink to cut the windshield for the countersunk screws.

Revision Date: March 1, 2004



6802

INSTRUCTIONS FOR WINDOW INSTALLATION SPACER KIT

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	3505	Rubber spacer 1/2 x 3/4 x 15
2	50	3405	Countersunk bolt 10 - 32 x 1"
3	50	3212	Locknut 10 - 32

The rubber spacer is designed to sit between the stock windshield ledge and the Lexan windshield. The rubber will space the window out 1/2 inch, which is enough to make the windshield flush with the body in most cars.

1. Cut the spacer to the correct length for the four sides of the window opening. Use a weather strip adhesive to glue the rubber to the frame.
2. Place the Lexan window in place and drill 3/16 inch holes through the window, the rubber and the stock window flange. Space the bolts 4 to 5 inches apart.
3. Use an 82 degree countersink to cut the windshield for the countersunk screws.

Revision Date: March 1, 2004

