

**6247****INSTRUCTIONS FOR ELIMINATOR II 6 DEGREE  
REAR SHOCK MOUNT**

<b><u>ITEM</u></b>	<b><u>QTY</u></b>	<b><u>PART NO.</u></b>	<b><u>DESCRIPTION</u></b>
1	1	1419	Adjustable shock mount housing driver side
2	1	1420	Adjustable shock mount housing passenger side
3	4	3209	Locknut 3/8 - 24
4	2	3200	Locknut 1/2 - 20
5	4	3121	Bolt 3/8 - 24 x 1 3/4
6	2	3100	Bolt 1/2 - 20 x 2 1/4
7	4	1000	Misalignment bushing 1/2"
8	4	3109-050-S-2-Y	Aircraft washer, 1/2"

This adjustable rear shock mount can be used with #6246 Eliminator II 4-link and #6206 Avenger 4-link. It can also be used with optional adjustable shock mounts on direct fit bolt-in FAB9™ housings.

1. Bolt the shock mounts between the 4-link axle brackets in between the rows of 3/8-inch holes. Use the 3/8 bolts and locknuts. The mount labeled "D" is for the driver's side. The mount labeled "P" is for the passenger's side.

2. Adjustable mount can be used with different width shock absorber spherical bearings by choosing the proper width spacers. Install shock into the mount with correct spacers and secure with 1/2" bolt and locknut.

- A. Place a 1/2" misalignment bushing on each side of 5/8" wide spherical bearing.
- B. Place a 1/16" thick washer on each side of 1" wide spherical bearing.
- C. No additional spacers are required on a 1-1/8" wide spherical bearing.

Revision: November 26, 2007

