

6267 COIL OVER 48" UPPER CROSSMEMBER WITH BOLTS AND TABS

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	E26.134-048.000	Tube 1 5/8 x .134 ERW 48"
2	4	2101	Bracket 1/2" hole
3	4	3100-050F2.50Y	Bolt 1/2-20 x 2-1/2"
4	2	3101-050-20C	Locknut 1/2-20

This crossmember can be used with any lower shock mount kit. Depending on the style of the lower mount, it can be installed in front of or behind the rear end.

1. Three brackets weld on the crossmember 1-1/16" to 1-5/16" apart. The brackets need to be 1-5/16" apart when using Chassisworks' Coil-Spring Assembly or VariShock Poly-Eye Coil-Overs. VariShock spherical-bearing coil-overs use 1-1/8" spacing.
2. For 5" travel shocks, install the mounts so there is 13" to 13-1/4" at ride height between the upper and lower mounts.
3. After tacking the upper and lower mounts in place, move the suspension through its full travel to make sure the springs and/or shocks do not bind on any part of the rear end or chassis.

Revision Date: August 08, 2011

