

6281

ADJUSTABLE LOWER COIL OVER MOUNT SUSPENSION BRACKET MOUNTING

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	2309	Lower bracket, right
2	2	2310	Lower bracket, left
3	2	2139	Adjustable shock mount suspension mount
4	2	3200	Locknut 1/2 - 20
5	4	3209	Locknut 3/8 - 24
6	4	3115	Bolt 3/8 - 24 x 1 1/4
7	2	3100	Bolt 1/2 - 20 x 2 1/4

This mount provides approximately 6" of height adjustment for the lower coil over mount.

1. Position the axle brackets on the housing. The brackets mount behind the rear-suspension axle brackets. The adjustment holes must be 90 degrees to the ground (viewed from the side). The brackets can be vertical or tilted inward at the top up to 10 degrees (viewed from the rear).

2. Bolt one right and one left bracket on each axle bracket. VariShock coil-overs have misalignment bushings built in to the shock eyes. Other brands of shocks may require optional misalignment bushings (P/N 1000) on each side of the coil over shock to take up the space between the brackets. The "L" shaped right and left can point up or down depending on where you want to position them. Be sure that there is at least one empty hole between the 3/8" mounting bolts.

Revision Date: September 23, 2010

